

CF124

KTM 690 Enduro R 2019- Husqvarna 701 Enduro/Supermoto 2016-2020

Kit for Left Side

ID.	Description	Cat. No.	Pcs
1	Top Crash Frame	CF122	1
2	Screw M10x60mm	850	2
3	Frame insertion (d=16mm)	499	1
4	Frame insertion (d=13mm)	1143	1
5	Washer M10-spring	804	2
6	Plastic cap for frame	X19	2
7	Strut	X125	1
8	Washer M10-flat	804	1
9	Safety nut M10	810	1
10	Dural. roller d=22mm	1337	1
11	Screw M10x50mm	849	1
12	AL screw cap	X115	1
13	Plastic cap for Allen bolt	X4	1
14	Lower frame	CF123	1
15	Screw M6x20mm	1022	3
16	Washer M6 – flat	947	3
17	Washer M6 – large	987	3
18	Safety nut M6	948	3

Kit for Right Side

ID	Description	Cat. No.	Pcs
1	Top Crash Frame	CF122	1
2	Screw M10x60mm	850	2
3	Frame insertion (d=16mm)	499	1
4	Frame insertion (d=13mm)	1143	1
5	Washer M10-spring	804	2
6	Plastic cap for frame	X19	2
7	Screw M10x180mm	978	1
8	Washer M10-flat	804	1
9	-----	---	
10	Dural. roller d=22mm	1337	1
11	Screw M10x50mm	849	1
12	AL screw cap	X115	1
13	Plastic cap for Allen bolt	X4	1
14	Lower AL cover	X124	1
15	Screw M6x20mm	1022	3
16	Washer M6 – flat	947	3
17	Washer M6 – large	987	3
18	Safety nut M6	948	3

Mounting Instructions:

Follow steps and instructions on the attached photographs.

First, uninstall the lower original plastic cover.

Then, mount strut X125 into the frame, but don't tighten it yet.

Mount the lower frame in rear part into rubber brackets and lean it towards the X125 strut. Attach it slightly by M10x50mm screw on one side.

Now take off screws in the left top frame part and insert brackets (wider bracket for the top hole).

Take the left crash frame and screws M10x60mm, mount it into motorcycle frame with spring washers (don't tighten yet).

Do the same with the top right crash frame.

Now, the top frame should meet lower frame in the area of X125 strut, take screws M10x50mm, equip them with the AL screw covers and mount into thread on the X125 strut. Use the plastic allen bolt covers to hide screw heads.

Now you may tighten all screws and use plastic covers on the top frame.
 If you encounter any problem during assembly, please do let us know!

Thank you for purchasing RDMoto products.

Note: We recommend using medium strenght glue for threads of all screws.

