

CF95

Benelli TRK 502 2017-

Kit for left side			
ID	Popis	Kat.č.	ks
1	Crash Frame	CF95	1
2	Bolt M10x140	953	1
3	Self locking nut M10	810	1
4	Washer M10 flat	804	2
5	Dural. roller d=8mm	229	1
6	Washer M8 flat	802	2
7	Bolt M8x20	823	2
8	Tube plug M10	X5	1
9	Tube plug M8	X4	2
10	Sticker RDmoto		1

Kit for right side			
ID	Popis	Kat.č.	ks
1	Crash Frame	CF95	1
2	Bolt M10x150	939	1
3	Self locking nut M10	810	1
4	Washer M10 flat	896	1
5	Dural. roller d=8mm	229	1
6	Washer M8 flat	802	2
7	Bolt M8x20	823	2
8	Tube plug M10	X5	1
9	Tube plug M8	X4	2
10	Sticker RDmoto		1

We recommend using medium strenght thread glue.

Mounting instructions (same for both sides):

- 1.) Complete one side fully before proceeding to the other one.
- 2.) Remove bolts and the original frame from your motorcycle.
- 3.) Being assembling the left side first.
- 4.) In the bottom part, fit the frame over the rubber hose.
- 5.) Using bolt ID.2 push through frame ID.1 and roller ID.5 and slightly attach it from inside using M10 ID.4 washer and M10 ID.3 nut (dont tighten yet)
- 6.) Then, fix the frame at the top part using M8 ID.7 bolt and M8 ID.6 washer.
- 7.) Proceed fixing the left bottom part of frame using ID.7 bolt and ID.6 washer.
- 8.) Finally, tighten all screws and insert tube plugs ID.8 and ID.9.



